
Whirlpool

VENTILATION PARTS

For Model: GZ7736XGS1 (Stainless Steel)

30" RANGE HOOD (Use with Gas or Electric Range)




VENTILATION PARTS

For Model: GZ7736XGS1 (Stainless Steel)

IIIus. No.	Part No.	DESCRIPTION
1		Literature Parts
'	9763393	Instructions, Installation
2	4360082	Wiring Diagram
2		Hood, Canopy Non-serviceable
3	4360002	Support, Canopy (2)
4		Bracket, Blower
	4360003	Left Side
5	4360054	Right Side Support, Housing
5		Housing
	4360004	Left Side
	4360039	Right Side
6	4360005	Washer
7	4360006	Screw, 5 x 12 (3)
8	4000007	Endcap, Blower
	4360007	Left
9	4360053 4360008	Right Housing, Blower
10	4360075	Support, Housing
11	4360063	Bushing (4)
12	4360062	Strain Relief
13	4360357	Plate, Mounting
14		Cover, Terminal
	4360060	Left Side
4.5	4360056	Right Side
15 16	4360057 4360058	Terminal Capacitor
17	4360059	Bracket, Capacitor
18	.000000	Wheel, Blower
	4360049	Left Side
	4360055	Right Side
19	4360040	Motor
20	4360052	Plate, Motor
21 22	4360050 4360051	Screw 4 x 8 (3) Washer (3)
23	4360064	Grille, Blower (2)
24	4360067	Screw 6 x 10 (2)
25	4360074	Clip (2)
26	4360048	Pin, Filter (2)
27	4360071	Bracket, Filter
28	4360072	Spring, Filter (2)
29	4360120	Bracket (6)
30	4360001	Damper, Canopy

DOOR AND CONTROL PARTS For Model: GZ7736XGS1 (Stainless Steel) - 5 32 31 9



DOOR AND CONTROL PARTS

For Model: GZ7736XGS1 (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1 2	4360010	Guide, Door (2) Guide, Housing
	4360011	Left Side
	4360037	Right Side
3	4360012	Support, Guide
4	4360013	Socket, Lamp (2)
5	4360014	Lamp
6	4360015	Filter
7	4360076	Glass, Door
8	4360017	Brace, Glass (2)
9		Frame, Door
	4360018	Left Side
	4360024	Right Side
10		End Cap, Door
	4360069	Left Side
	4360070	Right Side
11	4000000	End Cap Handle
	4360020	Left Side
40	4360022	Right Side
12	4360358	Handle
13	4360112	Bracket, Handle
14	4360077	Baffle, Door
15 16	4360080	Support, Light End Plate
16 17	4360066 4360043	Bracket, Light
18	4360043	Clamp, Wiring
19	4360044	Ballast, Lamp
20	4360047	Receptacle
21	4360046	Starter
22	4360041	Brace, Glass (2)
23	4360041	Lens, Light
24	4360081	Frame, Lens
25	4360033	Base, Switch
26	4360034	Cover, Base
27	4360035	Switch (2)
28	4360036	Cover, Switch
29	4360073	Screw
30	4360025	Switch, Light (2)
31	4360359	Light, Indicator
32	4360027	Switch, Fan (2)
33	4360028	Lens, Ind. Light
34	4360029	Cover, Switch
35	4360030	Knob, Control
36	4360031	Knob, Fan
37	4360032	Knob, Light

ACCESSORY PARTS

883140 Non-Vent Kit 883142 Front Kit (Black) 883144 Front Kit (White)